

# Indirect Visual Odometry with Optical Flow

Chenguang Huang, Andong Tan

München, 22. July 2019



# Overview

## **1. Introduction**

1.1 Lukas Kanade Method for Optical Flow

1.2 Project Pipeline

1.3 Parameter and Strategy

## **2. Evaluation**

2.1 Precision Comparison

2.2 Execution Time Comparison

2.3 Visualization Comparison


## **3. Conclusion**

# 1 Introduction


## 1.1 Lukas Kanade method for optical flow

Input: two images, key points in one image

Output: the key points in the other image



Input key point position in one image




Output key point position in the other image

# 1 Introduction


## 1.1 Lukas Kanade method for optical flow

Inspiration in SLAM:

replace feature descriptors matching with optical flow method!




Input key point position in one image



Output key point position in the other image


# 1 Introduction



# 1 Introduction

## 1.2 Project pipeline: first key frame


Step 1: detect key points in left image



# 1 Introduction

## 1.2 Project pipeline: first key frame


Step 2: optical flow to right image



# 1 Introduction

## 1.2 Project pipeline: first key frame

Step 3: check epipolar constraint and find inlier






# 1 Introduction

## 1.2 Project pipeline: first key frame


Step 4: localize camera



# 1 Introduction

## 1.2 Project pipeline: first key frame


Step 5: triangulate landmarks



# 1 Introduction

## 1.2 Project pipeline: second and later key frame


Step 1: optical flow to next left frame



# 1 Introduction

## 1.2 Project pipeline: second and later key frame


Step 1: optical flow: backward check



# 1 Introduction

## 1.2 Project pipeline: second and later key frame


Step 2: make grid & detect key points in empty cells



# 1 Introduction

## 1.2 Project pipeline: second and later key frame


Step 3: optical flow to the right image



# 1 Introduction

## 1.2 Project pipeline: second and later key frame


Step 4: use epipolar constraint to find inliers



# 1 Introduction

## 1.2 Project pipeline: second and later key frame

Step 5: localize camera






# 1 Introduction

## 1.2 Project pipeline: second and later key frame


Step 6: add observation and create landmarks



# 1 Introduction

## 1.2 Project pipeline: non key frame


Step 1: optical flow to next frame



# 1 Introduction

## 1.2 Project pipeline: non key frame


Step 2: make grid & count empty cells



# 1 Introduction

## 1.2 Project pipeline: non key frame

Step 3: localize camera



# 1 Introduction

## 1.3 Parameter and strategy

### 1.3.1 Grid shape: rectangle vs square

pixel x pixel




30 x 47

32 x 32

rmse

0.14

0.11




# 1 Introduction

## 1.3 Parameter and strategy


### 1.3.2 Key points detection: in whole image vs in each cell

Detect in whole image  
Then only keep key points in empty cells



rmse

0.1139



Detect in empty cells respectively

0.1116


# 1 Introduction

## 1.3 Parameter and strategy

### 1.3.3 Key framing: use grid vs use only inliers number

# empty cells

If greater than  
threshold, make  
next frame  
key frame




rmse

0.11

# localization  
inliers

If smaller than  
threshold, make  
next frame  
key frame



0.43

# 2 Evaluation



## 2 Evaluation

### 2.1 Precision comparison

Basic parameters

image height (pixel)	image width (pixel)	grid size (pixel x pixel)
480	752	32 x 32

#### Strategy

1. Square grid
2. Key points detection only in empty cell
3. Use number of empty cells to decide key frame

## 2 Evaluation

### 2.1 Precision comparison

Variation parameters: maximum empty cells percentage\*


Max empty cells	35%	40%	42%	44%	46%	Exercise 5
rmse	0.1303	0.1295	<b>0.1099</b>	0.1563	0.1304	<b>0.1012</b>

\*maximum empty cells percentage: when the empty cells percentage exceeds this value and optimization is finished, make next frame key frame

## 2 Evaluation

### 2.1 Precision comparison

empty cells percentage vs rmse



## 2 Evaluation

### 2.2 Execution time comparison

#### 2.2.1 Detection time

Max empty cells	35%	40%	42%	44%	46%	Exercise 5
detection time (seconds)	3.03643	2.73232	2.43286	2.62328	2.26326	<b>44.0214</b>

## 2 Evaluation

### 2.2 Execution time comparison

#### 2.2.2 Optimization time

Max empty cells (%)	0.42	Exercise 5
Opt. time(s)	305.043	<b>65.8619</b>
# landmarks	290657	<b>221886</b>
# observation	1939460	<b>559563</b>
# keyframe	414	<b>170</b>

## 2 Evaluation

### 2.2 Execution time comparison


#### 2.2.3 Frame to frame (f2f) optical flow time

Ex. 5 Feature Matching time(s)	5.79
f2f optical flow time(s)	117.4~143.1

## 2 Evaluation

### 2.3 Visualization comparison


Maximum empty cells percentage: 42%



## 2 Evaluation

### 2.3 Visualization comparison

#### Exercise 5






## 2 Evaluation

### 2.3 Visualization comparison

Maximum empty cells percentage: 42%

Exercise 5



## 2 Evaluation

### 2.3 Visualization comparison




## 2 Evaluation

### 2.3 Visualization comparison

Maximum empty cells percentage: 42%

Exercise 5



### 3 Conclusion

1. Use Lucas and Kanade Optical Flow method to replace normal feature matching.
2. Try different key framing strategies: use grid or only inliers.
3. Try different configurations (e.g. shape of grid, key points detection strategies)
4. Visualize the ground truth and estimated trajectories of camera
5. Evaluation

Q&A

Any question?

Thank you for your attention!